

Few-Shot Fine-Tuning of Stable Diffusion XL for Defect Image Generation

Babak Badnava

August 12, 2025

Project Overview

- ▶ Goal: Generate high-quality synthetic images of defective pills (e.g., **color** or **scratch** defects) from few-shot examples.
- ▶ Approach:
 1. Sample small subsets from real dataset.
 2. Fine-tune **Stable Diffusion XL** with LoRA and/or Textual Inversion.
 3. Generate synthetic images conditioned on defect type.
 4. Evaluate quality using standard image generation metrics.
- ▶ Supports **multiple defect types** and different sample sizes.

Model Selection

Chosen Models:

- ▶ **SDXL Base 1.0:**
 - ▶ High-resolution generation (1024×1024).
 - ▶ Well-suited for fine detail (important for defect representation).
- ▶ **SDXL Refiner 1.0:**
 - ▶ Refines base model outputs for sharper textures.
 - ▶ Especially helpful for subtle defects.

Why good for this task?

- ▶ Pretrained on large, diverse datasets → strong visual priors.
- ▶ LoRA fine-tuning → efficient adaptation to new visual concepts.

Dataset and Preprocessing

- ▶ Dataset contains multiple defect types: *color*, *scratch*, etc.
- ▶ **Few-Shot Sampler** selects N samples for a given defect.
- ▶ Data is split for:
 - ▶ LoRA fine-tuning
 - ▶ Textual Inversion
- ▶ Masks and captions:
 - ▶ Masks localize defects for inpainting.
 - ▶ Captions describe object and defect ("*a macro photo of a pill with a color defect*").

Pipeline Workflow

1. Few-shot sampling. Distributed and scalable.
2. Fine-tuning (LoRA + TI).
3. Inference: Generate synthetic images.
4. Evaluation: Compare to real dataset.

Evaluation Metrics

- ▶ **ISC** (Inception Score): Measures image quality and diversity.
- ▶ **FID** (Frechet Inception Distance): Measures realism by comparing distribution of features.
- ▶ **KID** (Kernel Inception Distance): Similar to FID but unbiased.
- ▶ **PRC** (Precision Recall for Distributions): Measures coverage and fidelity of generated samples.



Using Segmentation Masks in Fine-Tuning

- ▶ **Purpose:** Highlight the defective region so the model focuses learning on relevant areas.
- ▶ In **inpainting fine-tuning**, the mask tells the model:
 - ▶ Which pixels to **replace** (defect region).
 - ▶ Which pixels to **keep** (background / non-defective areas).
- ▶ This improves:
 - ▶ **Defect localization** (model learns where defects occur).
 - ▶ **Sample efficiency** (few-shot training focuses on critical areas).



base image



mask image



generated image

Using Masks in Inference and Generation

- ▶ During inference, masks allow:
 - ▶ **Defect injection:** Generate a defect only in a given masked area.
 - ▶ **Defect removal or replacement:** Inpaint over defective area.
- ▶ Workflow:
 1. Provide *initial image + segmentation mask*.
 2. Specify prompt (e.g., “a pill with a scratch defect”).
 3. Model edits only masked region, preserving the rest.

Benefit

Mask-guided generation increases **control**, **accuracy**, and **consistency** of defect placement.

Results and Next Steps

► **Results:**

- Generated images closely match defect type and preserve pill structure.
- LoRA + TI improves fine detail and defect accuracy.

► **Next Steps:**

- Extend to additional defect types.
- Experiment with Refiner model for all outputs.
- Experiment with Inpainting model to incorporate masks for defect generation.
- Automate hyperparameter search for better few-shot adaptation.

References and Acknowledgments

- ▶ Hugging Face Diffusers Library.
- ▶ Stability AI Stable Diffusion XL.
- ▶ ISC, FID, KID, PRC evaluation methods from literature.